

## BKA30D-XX Double Shaft Stepper Motor Description

The BKA30D-XX Double Shaft Stepper Motor is a patented design with a reduction ratio of 180/1. Its innovation is based on the BKA30-xx model. The BKA30D can drive two pointers independently. The benefits include a dial space saving opening a window for new concept designs. Applications include dashboards and digital indicator equipment to transfer digital signals to an analog display.


The BKA30D-XX Double Shaftstepper motor requires two logic pulse signals to drive, and can operate under pulses of 3.5V~10V. The minimum step angle of the output shaft can reach 1/12 degree. Can be driven in either step-by-step or micro step mode.

### Features:

- High Resolution: 1/3° resolution per partial step, 1/12° resolution per micro step
- Low Consumption: mean operation current 18 mA
- Small Dimensions: 59.5 x 31.5 x 8.9 mm
- Large Operation Temperature Range: -40~105 °C
- Large Running Speed Range: 0~600° /s
- High Reliability: Qualified for automotive applications
- Silent & Longevious: lubricative and high intensity material for gears,When two motors are running simultaneously, the noise level is as low as 45dB (A).



### Typical Application:



perfect combination of digital accuracy and analog facility

Fig-1

## Electronics and Mechanical Characteristics


Parameter	Sym.	Test Conditions	Min.	Type	Max.	Units	
Operating Temperature	Ta		-40	/	105	°C	
Coil Resistance	Rb		260	280	300	Ω	
Operating Current	I <sub>m</sub>	f <sub>z</sub> =200Hz	/	/	20	mA	
Magnetic Saturation Voltage	U <sub>bs</sub>		/	/	9	V	
Start-Stop Frequency	f <sub>ss</sub>	JL=2E-7Kg/m*2	/	/	200	Hz	
Maximum Driving Frequency	f <sub>m</sub>	JL=2E-7Kg/m*2	/	/	600	Hz	
Dynamic Torque	Outer shaft	M200	f <sub>z</sub> =200Hz	0.7	0.8	/	
	Internal shaft			1.05	1.2	/	
	Outer shaft	M400	f <sub>z</sub> =400Hz	0.5	0.6	/	
	Internal shaft			0.75	0.9	/	
Static Torque	Outer shaft	Ms	Ub=5V	3.5	4	/	
	Internal shaft			3.5	4	/	
Axial Push-on Force on shaft	Outer shaft	F <sub>A</sub>		/	/	60 N	
	Internal shaft			/	/	180 N	
Axial Pull-off Force on shaft	Outer shaft	F <sub>a</sub>		/	/	60 N	
	Internal shaft			/	/	70 N	
Radial Force on shaft	Outer shaft	F <sub>p</sub>		/	/	5 N	
	Internal shaft			/	/	13 N	
Holding Torque on shaft	Outer shaft	T <sub>h</sub>		110	/	/	
	Internal shaft			100	/	/	
Imposed Acceleration	α <sub>p</sub>			/	/	1000 Rad/s <sup>2</sup>	
Angle of Rotation	Outer shaft	β		/	/	320 Degree	
	Internal shaft			/	/	270 Degree	
Noise Lever	SPL		f <sub>z</sub> =400Hz	/	40	50 dB(A)	
Backlash	σ			/	0.7	1.2 Degree	
***T <sub>amb</sub> =25°C, Ub=5V;unless otherwise specified***							

Table-2

## Absolute Maximum Ratings


Parameter	Symbol	Value
Driving Voltage	Ub	10V
ESD Tolerance	UESD	10,000V
EMI Tolerance (1KHz, AM80%, 100KHz-2GHz)	E	80V/m
Solder Temperature	T <sub>s</sub>	260°C

Table-3

## Typical Performance Characteristics


Internal shaft

Fig-3-1



Outer shaft

Fig-3-2



### Motor Mounting:

The BKA30D series motor has 8 pins that can be directly soldered to the PCB board. If working in a highly vibrating environment, it is recommended to install 4 ST2.0 screws for fixation.




Fig.6

--As a general rule, screws are unnecessary and should be avoided as much as possible, both for cost and process capability reasons. The motor has a robust design but normal care should be taken that excessive force do not deform the housing, especially when assemble the pointer, in this case we suggest to add an additional support on the bottom of the motor during pointer

assembly process against the push force on the pointer shaft.

### Mounting Load on Pointer Shaft

The load mounting on the pointer shaft, such as a pointer, gear, etc. is usually in a pressing operation. When using this technique, care should be taken that the force do not exceed those given in the specification (see Table2).




Fig.9

### **Functional Description**

#### General

-- The BKA30D series stepper motor consists of two independent motor parts and a gear transmission chain part. The built-in three-stage gear transmission chain has a reduction ratio of 180/1, which enables a full step drive signal, that is, a rotor rotation of 180 degrees, to ultimately be reflected as an output shaft rotation of 1 degree.




Fig.10

--As mentioned earlier, a partial step is an angular rotation of  $1/3^\circ$  of the motor shaft or an angular rotation of  $60^\circ$  of the rotor. The motor also can be driven directly by micro step, and a micro step is an angular rotation of  $1/12^\circ$  of the motor shaft or an angular rotation of  $15^\circ$  of the rotor (see Fig.11). The micro stepping allows a continuous smooth movement of a pointer if the motor is used as a pointer driver.




Fig.11

## Driving Diagram




Fig.12

## Noise Lever

### Test Configuration

1. reflection free room
2. microphone
3. sonometer
4. motor under test
5. reflection free cube
6. control unit in micro step mode (1/12° / step)

### Test Conditions

- temperature	Tamb :	25	°C
- measurement distance	Lm :	4	cm
- measurement range	:	20 - 20k	Hz
- measurement time	tm :	4	s
- angular speed max	$\omega$ :	600	°/s
- ambient noise max	:	20	dBA
- motor without load.			




Fig.13

## Typical Noise performance

The Fig. 14 shows a typical curve of two motors running simultaneously::




Fig.14

## Start-Stop frequency

The Fig.15 show the relation of Start-Stop Frequency ( $f_{ss}$ ) & the inertia of the pointer load ( $J_p$ )




Fig.15

## Frequency Acceleration

The Fig.16 show the acceleration of the pointer shaft ( $\alpha$ )@ different running frequency, and if the motor is running at frequency  $f_o$ , the maximal frequency of next step can be given is  $f_i$  as specified in the Fig.17




Fig.16




Fig.17

## Reliability Test Conditions

### Indicator Normal Load

--mass : 2.5g  
 --inertia : 2E-7Kgm<sup>2</sup>  
 --unbalance : 0.01mNm

### Temperature Cycle

--Low temperature: -40°C±2°C  
 --High temperature: +105°C±2°C  
 --Dwell time: see Fig.18  
 --6hrs/per cycle, running for 50cycles,  
     Total 300hours  
 --Status: running@0~600Hz sweep  
 --Quantity of samples: 20pcs  
 --Reference standard: IEC60068-2-14:1984




Fig.18

### Thermal Shock

--Low temperature: -40°C±2°C  
 --High temperature: +105°C±2°C  
 --Dwell time: half an hour for each  
 --Transfer time: Within 30s  
 --Cycles: 100, total 100hours  
 --Status: non-running  
 --Reference standard: IEC60068-2-14:1984

### Longevity

--Temperature: 105°C±2°C  
 --Storage time: 1000hours  
 --Status: running@600Hz  
 --Quantity of samples: 10pcs  
 --Reference standard: GB/T 2689.1-1981



**BKA**  
BACTRIANUS MOTOR

## BKA30D-R5 Stepper Motor Specification

BKA30D-XX

### High Temperature Storage

--Temperature:  $105^{\circ}\text{C} \pm 2^{\circ}\text{C}$   
--Storage time: 72hours  
--Status: non-running  
--Quantity of samples: 10pcs  
--Reference standard: IEC60068-2-2:1974

### Mechanical Shock

--Shock model: vibration  
--Pulse waveform: sine  
--Peak of acceleration: 50g/11ms  
--Shock times: 5  
--Shock direction: axial/radial  
--Status: non-running  
--Quantity of samples: 10pcs  
--Reference standard: IEC68-2-27:1987

### Low Temperature Storage

--Temperature:  $-40^{\circ}\text{C} \pm 2^{\circ}\text{C}$   
--Storage time: 72hours  
--Status: running@ non-running  
--Quantity of samples: 10pcs  
--Reference standard: IEC60068-2-1:1990

### Mechanical Vibration




--Pulse waveform: sine  
--Frequency: 5~200Hz, logarithm sweep  
--Sweep Speed: 3 Oct/Min  
--Acceleration: 6g  
--Amplitude: 13.2mm  
--Vibration direction: axial/radial  
--Vibration time: 22hours/each direction  
-- Status: running@0~600Hz sweep  
--Quantity of samples: 20pcs

### Humidity Storage

--Reference standard: IEC68-2-6:1982

--Temperature:  $80^{\circ}\text{C} \pm 2^{\circ}\text{C}$   
--Humidity:  $85 \pm 2\% \text{ RH}$   
--Storage time: 168hours  
--Status: non-running  
--Quantity of samples: 20pcs  
--reference standard: IEC68-2-67:1995

## Package Information

<p>Weight :Stacks 1x9410g = 9410g          Plastic strap 2x15g = 30g          Total = 9440g</p>	
<p>Master-carton for 300 Pcs Motor:          Material : carboard 710g/m<sup>2</sup>          Weight :Master-carton 1x930g = 930g          PE bag 1x105g = 105g          Stacks 1x8115g = 8115g          EPE 4x65g = 260g          Total = 9410g</p>	
<p>Stack for 300 Pcs Motor          Material : 11Trays (including Cover)strapped          together with plastic band          Weight :Tray+Motors 10x777g = 7770g          Cover tray 1x315g = 315g          Plastic straps 2x15g = 30g          Total = 8115g</p>	
<p>Tray for 30Pcs Stepper Motor          Material : PP(Nat)          Weight :Tray 1x360g = 315g          Motor 30x15.4g = 462g          Total = 777g</p>	